


**Messobjekt: EMV-Malergewebe**

Obere Messkurve: Frequenzbereich 200MHz - 2200MHz Untere Messkurve: Frequenzbereich 1 GHz - 10 GHz

S21 FORWARD TRANSMISSION


LOG MAG.      ▶REF=0.000dB      10.000dB/DIU



▶START  
0.200 GHz  
STOP  
2.2000 GHz  
169 DATA PTS,  
12.0 MHz  
STEP SIZE  
C.W. MODE OFF  
MARKER SWEEP  
DISCRETE FILL  
HOLD BUTTON  
FUNCTION  
REDUCED TEST  
SIGNALS  
PRESS ◀ENTER▶  
TO SELECT  
OR TURN ON/OFF

S21 FORWARD TRANSMISSION

LOG MAG.      ▶REF=0.000dB      10.000dB/DIU



▶START  
1.0 GHz  
STOP  
10.0000 GHz  
168 DATA PTS,  
54.0 MHz  
STEP SIZE  
C.W. MODE OFF  
MARKER SWEEP  
DISCRETE FILL  
HOLD BUTTON  
FUNCTION  
REDUCED TEST  
SIGNALS  
PRESS ◀ENTER▶  
TO SELECT  
OR TURN ON/OFF